Tightening torque

Stage 1 = 60 Nm
Stage 2 = 300 Nm

Use a torque spanner to ensure that the specified torques are accurately maintained.